





PL

UWAGA

1. Przed zainstalowaniem oprawy lub naprawą należy wyłączyć zasilanie elektryczne.
2. Montaż wykonywać zgodnie z zaleceniami producenta. W przypadku wątpliwości należy skonsultować się z uprawnionym elektrykiem.

INSTRUKCJA UŻYTKOWANIA WYROBU

1. Wyrób należy stosować tylko zgodnie z przeznaczeniem.
2. Montaż należy wykonać zgodnie z powyższą instrukcją.
3. Producent nie ponosi odpowiedzialności za urazy oraz szkody wywołane nieprawidłowym montażem oraz użytkowaniem wyrobu.
4. Nie stosować źródeł światła innych niż zalecane. Nie przekraczać podanej mocy.

WARUNKI GWARANCJI

1. Na wykonane wyroby producent udziela 36-miesięcznej gwarancji od daty zakupu, zgodnie z OWG dostępnymi na stronie: <https://www.elmarco.pl/dokumenty/>
2. Gwarancja nie obejmuje uszkodzeń mechanicznych (w tym pęknięć, zarysowań, pocięć, itp.) oraz innych uszkodzeń wynikających z nieprawidłowego montażu lub użytkowania wyrobu.
3. W przypadku ewentualnych reklamacji należy dostarczyć dowód zakupu.

1. Wspornik montażowy (A) oraz gniazdo zawiesia linki (B) przymocować do sufitu wkrętami.
2. Do wspornika (A) przykręcić śruby M3 pozostawiając 2-3 mm luzu.
3. Uchwyt zawiesia (B) z linką wkręcić w gniazdo.
4. Połączyć przewody zasilające:
żółtozielony - uziemienie,
niebieski - neutralny,
brązowy lub czarny - przewód napięciowy.
5. Nałożyć podsufitkę na wspornik (A) i przykręcić śrubami M3.
6. Wyluzować zaciski (C) i ustalić długość linek.

Ustawa o zużyтым sprzęcie elektrycznym i elektronicznym zabrania umieszczania w koszach z innymi odpadami sprzętu elektrycznego i elektronicznego. Zbiórkę prowadzą dystrybutorzy oraz gminne jednostki odbioru i odzysku sprzętu elektrycznego i elektronicznego.



UK

IMPORTANT

1. Switch off the electric energy before installing or repairing the fixture.
2. Install according to the manufacturer's guidelines. If in doubt consult a qualified electrician.

INSTRUCTIONS FOR USE

1. This fixture is to be used only according to its purpose.
2. Follow the above instructions for the installation.
3. The manufacturer will not accept liability for injury or any damage resulting from incorrect installation or use of this product.
4. Do not use light source other than indicated on the product. Do not exceed the maximum power indicated.

WARRANTY

1. The manufacturer gives the 36 month warranty for this product, beginning from the date of purchase, according to conditions presented on the website: <https://www.elmarco.pl/en/dokumenty>
2. The warranty does not include mechanical damages (incl. cracks, scratches, bends, etc.) as well as other damages resulting from incorrect installation or use of the product.
3. In case of reclamation, please attach the bill of sale.

1. Fasten the mounting support (A) and cable sling socket (B) to the ceiling with screws.
2. Screw the M3 screws to the mounting support (A), leaving 2-3 mm of clearance.
3. Screw the sling holder (B) with the cable into the socket.
4. Connect the cables with the installation slot:
yellow/green - earth,
blue - lead (neutral),
brown or black - live
5. Place the lamp canopy on the mounting support (A) and secure with M3 screws.
6. Loosen the clamps (C) and adjust the cable lengths.

The Act on Waste Electrical and Electronic Equipment prohibits placing electrical and electronic equipment in bins with other waste. Collection points are operated by distributors and municipal units for the collection and recovery of electrical and electronic equipment.

