

PL

1. Zainstalować zalecane źródło światła w oprawkę.
2. Podłączyć wtyczkę do gniazda zasilania.

UK

1. Instal the recommended light source into the socket.
2. Insert power plug into the outlet.

INSTRUKCJA UŻYTKOWANIA WYROBU

1. Wyrób należy stosować tylko zgodnie z przeznaczeniem.
2. Montaż należy wykonać zgodnie z powyższą instrukcją.
3. Producent nie ponosi odpowiedzialności za urazy oraz szkody wywołane nieprawidłowym montażem oraz użytkowaniem wyrobu.
4. Nie stosować źródeł światła innych niż zalecane.
Nie przekraczać podanej mocy.

WARUNKI GWARANCJI

1. Na wykonane wyroby producent udziela 36-miesięcznej gwarancji od daty zakupu.
2. Gwarancja nie obejmuje uszkodzeń mechanicznych. (w tym pęknięć, zarysowań, pocięć, itp.) oraz innych uszkodzeń wynikających z nieprawidłowego montażu lub użytkowania wyrobu.
3. W przypadku ewentualnych reklamacji należy dostarczyć dowód zakupu.

Ustawa o zużyтым sprzęcie elektrycznym i elektronicznym zabrania umieszczania w koszach z innymi odpadami sprzętu elektrycznego i elektronicznego. Zbiórkę prowadzą dystrybutorzy oraz gminne jednostki odbioru i odzysku sprzętu elektrycznego i elektronicznego.




INSTRUCTIONS FOR USE

1. This fixture is to be used only according to its purpose.
2. Follow the above instructions for the installation.
3. The manufacturer will not accept liability for injury or any damage resulting from incorrect installation or use of this product.
4. Do not use light sources other than indicated on the product. Do not exceed the maximum power indicated.

WARRANTY

1. The manufacturer gives the 36 month warranty for this product, beginning from the date of purchase.
2. The warranty does not include mechanical damages (incl. cracks, scratches, bends, etc.) as well as other damages resulting from incorrect installation or use of the product.
3. In case of reclamation, please attach the bill of sale.

The Act on Waste Electrical and Electronic Equipment prohibits placing electrical and electronic equipment in bins with other waste. Collection points are operated by distributors and municipal units for the collection and recovery of electrical and electronic equipment.



PL

1. Zainstalować zalecane źródło światła w oprawkę.
2. Podłączyć wtyczkę do gniazda zasilania.

UK

1. Instal the recommended light source into the socket.
2. Insert power plug into the outlet.

INSTRUKCJA UŻYTKOWANIA WYROBU

1. Wyrób należy stosować tylko zgodnie z przeznaczeniem.
2. Montaż należy wykonać zgodnie z powyższą instrukcją.
3. Producent nie ponosi odpowiedzialności za urazy oraz szkody wywołane nieprawidłowym montażem oraz użytkowaniem wyrobu.
4. Nie stosować źródeł światła innych niż zalecane.
Nie przekraczać podanej mocy.

WARUNKI GWARANCJI

1. Na wykonane wyroby producent udziela 36-miesięcznej gwarancji od daty zakupu.
2. Gwarancja nie obejmuje uszkodzeń mechanicznych. (w tym pęknięć, zarysowań, pocięć, itp.) oraz innych uszkodzeń wynikających z nieprawidłowego montażu lub użytkowania wyrobu.
3. W przypadku ewentualnych reklamacji należy dostarczyć dowód zakupu.

Ustawa o zużyтым sprzęcie elektrycznym i elektronicznym zabrania umieszczania w koszach z innymi odpadami sprzętu elektrycznego i elektronicznego. Zbiórkę prowadzą dystrybutorzy oraz gminne jednostki odbioru i odzysku sprzętu elektrycznego i elektronicznego.



INSTRUCTIONS FOR USE

1. This fixture is to be used only according to its purpose.
2. Follow the above instructions for the installation.
3. The manufacturer will not accept liability for injury or any damage resulting from incorrect installation or use of this product.
4. Do not use light sources other than indicated on the product. Do not exceed the maximum power indicated.

WARRANTY

1. The manufacturer gives the 36 month warranty for this product, beginning from the date of purchase.
2. The warranty does not include mechanical damages (incl. cracks, scratches, bends, etc.) as well as other damages resulting from incorrect installation or use of the product.
3. In case of reclamation, please attach the bill of sale.

The Act on Waste Electrical and Electronic Equipment prohibits placing electrical and electronic equipment in bins with other waste. Collection points are operated by distributors and municipal units for the collection and recovery of electrical and electronic equipment.

