





## **INSTALLATION GUIDE**


- 1. Place the foundation (F) down on a gravel bedding so that the installation plane is slightly above ground level.
- 2. Draw the electrical cable beyond the foundation leaving the appropriate reserve for
- 3. Cover the foundation with soil, tamping down each layer firmly.
- 4. Connect the fixture cable with the boom (lantern) cable using a connector. Power and grounding cables in accordance with markings.
- 5. Once connected, insert the connector into the fixture mounting bracket.
- 6. Place the fixture on the top of the pole or boom (in the case of "AS" optics, position the fixture so that the arrow points towards the illuminated surface).
- 7. Firmly tighten the tightening screws.
- 8. Place the pole base on the foundation bolts and screw in the M-14 mounting nuts tightening them firmly.
- 9. Connect the electrical cables to the connecting board and the grounding wire according to markings.

yellow/green - earth, blue - lead (neutral), brown/black - live,

- 10. After connecting, insert the connecting board into the column and attach it to the pole.
- 11. If it is necessary to replace the fixture power supply, unscrew the screws securing the upper cover to gain access to the equipment compartment.









- 1. Switch off the electric energy before installing the fixture.
- 2. Install according to the manufacturer's quidelines. If in doubt consult a qualified
- 3. The product can be connected to a network which meets the energy quality standards defined by the law.

## **INSTRUCTIONS FOR USE**

- 1. This fixture is to be used only according to its purpose.
- 2. Follow the above instructions for the installation.
- 3. The manufacturer will not accept liability for injury or any damage resulting from incorrect installation or use of this product.
- 4. Do not use light source other than indicated on the product. Do not exceed the maximum power indicated.

## WARRANTY

- 1. The manufacturer gives the 36 month warranty for this product, beginning from the date of purchase.
- 2. The warranty does not include mechanical damage (incl. cracks, scratches, bends, etc.) as well as other damages installation or use of
- 3. In case of reclamation, please attach the bill of sale.

