


UK

INSTALLATION GUIDE

1. Place the foundation (F) into the prepared hole on the gravel layer so that the mounting surface is **ca. 5 cm over the ground level**.
2. Draw the electrical cable beyond the foundation leaving the appropriate reserve for connection.
3. Cover the foundation with soil, tamping down each layer firmly.
4. Connect the electrical wires of the fixture and lantern boom using a connector. Power and ground wires according to the markings.
5. Once connected, insert the connector into the fixture holder.
6. Place the fixture mounting bracket onto the boom arm..
7. Position the fixture so that the  arrow points towards the illuminated surface.
8. Level and lock the fixture with 2. set screws on the mounting bracket.
9. Place the pole base on the foundation bolts and screw in the mounting nuts until they stop.
10. Connect the electrical cables in the installation box and the ground wire according to the markings.

yellow/green - earth (PE),
blue - lead (neutral) (N),
brown/black - live (L),

11. After connecting, insert the installation box into the column and attach to the pole.

IMPORTANT

1. Switch off the electric energy before installing or repairing the lantern or fixture.
2. Install according to the manufacturer's guidelines. If in doubt consult a qualified electrician.
3. This product has to be earthed. Electric wires: yellow/green - earth (PE), blue - lead (neutral) (N), brown - live (L), black - live (L).
4. The product can be connected to a network which meets the energy quality standards defined by the law.
5. Replacement of the light source is possible only by the manufacturer's service.

INSTRUCTIONS FOR USE

1. This product is to be used only according to its purpose.
2. Follow the above instructions for the installation.
3. The manufacturer will not accept liability for injury or any damage resulting from incorrect installation or use of this product.
4. Do not use light sources other than indicated on the product. Do not exceed the maximum power indicated.

WARRANTY

1. The manufacturer gives the 36 month warranty for this product, beginning from the date of purchase, according to conditions presented on the website: <https://www.elmarco.pl/en/dokumenty>
2. The warranty does not include mechanical damages (incl. cracks, scratches, bends, etc.) as well as other damages resulting from incorrect installation or use of the product.
3. In case of reclamation, please attach the bill of sale.

The Act on Waste Electrical and Electronic Equipment prohibits placing electrical and electronic equipment in bins with other waste. Collection points are operated by distributors and municipal units for the collection and recovery of electrical and electronic equipment.

